


Walk-In Liner Installation Instructions

scroll on to advance to the next page



Unroll liner in Container.



Tie 28' rope to rear of container and feed the rope through container lash rings. Tie off at front corner.



Next feed a rope through the floor container lash rings and tie to each corner or the last lash ring.




Locate the front top corner of the liner and secure the clips to the containers front top lash rings.



Locate the next set of clips moving toward the rear of the liner and secure to the suspension rope.




As you secure the ceiling ties, locate and secure the floor ties in the same method.
NOTE: It is important the liner can fully extend once the clips are secured.




Secure all the ceiling and floor ties to the suspension rope until you reach the container doors. At this point if possible secure the clip to the lash ring or channel bar.



The inside of the Walk-In liner should look similar to this.



Secure the (4) elastic loops to the top load locks. This keeps the ceiling tight and prevents sags.



The liner is now ready to load. Once loading is complete, gather the end together, twist and cable tie the opening closed.

